



MAGNET MEASUREMENT ON THE  
MEDICAL-LINE EXTRACTION MAGNETS  
32° H-TYPE AND 58° C-TYPE MAGNETS

D. Krause

July 15, 1975


On July 3 and 11, 1975, Hall probe measurements were made on the 32° H-type and 58° C-type bending magnets for the Medical Facility. Measurements were done on both magnets using a F.W. Bell 640 gaussmeter with a 0.1% transverse probe. A Dana 5500 Digital vollmeter was used for the external readout of field. An excitation curve from zero to 1200 Amperes was measured in a current-up and current-down mode to average errors from hysteresis and current settings.

The field shape in the x direction was also measured using the same Hall probe. The probe was hand-held and moved across a template on the gap spanning as much of the x distance as possible. The data were then normalized to percentage of the field measured at the center and graphed. The accuracy of the B vs. I data is about 1% and the field shape data is about 0.5% in the central region.

The internal transducer of the transrex 240 power supply which will power one of the magnets was used as the monitor of the current levels.


# Medical Magnets

H-Type 32°



turns =	48
Gap center =	1.625"
Gap (min) at ends of pole tip	1.588"
Width of Gap	10.125"
Steel length	16"
width	16.5"
height	11.5"
thickness	.0625"
Wire .325"x.325" square	
Cooling hole .180" dia.	
Coils	Normal wind
Chamber	None

C-Type 58°



Main turns	60 - (1)
Bucking coil (parallel) turns	60 - (2)
Auxiliary coil turns	18 - (3)
Gap center	1.375"
Gap (min) at ends of pole tip	1.250"
Gap width total	10"
Steel length	25"
width	17.5"
height	20.5"
thickness	.0625"
Wire main coil (1) .325"x.325"	
Cooling hole .180" dia.	
Wire boost coil (3) .125"x.125"	
no cooling	
Bucking (2) .015x.325"	
Chamber	None

Medical Magnets  
B verses I  
With T 6010 Hall Probe

Amps	32°	58°
	H-Type	C-Type
0	.013 kG	.030
120	1.67	2.78
240	3.34	5.53
360	5.02	8.28
480	6.67	10.98
600	8.34	13.61
720	9.97	16.04
840	11.56	18.04
960	13.09	19.60
1080	14.37	20.55
1200	15.46	-----

## Medical Magnet 32° H-Type

## Field-Shape Data

## Per Cent Change in Field

## From Center X-Direction

Position Centimeters	Run I Per Cent	Run II Per Cent	Run Ave Per Cent
1	-25.	-27.	-26.
2	-15.	-14.	-15.
3	-5.	-3.	-4.
4	-0.5	+.2	-.2
5	+0.2	0	+.1
6	0	0	0
7	0	0	0
8	0	0	0
9	0	0	0
10	-0.2	-3.5	-1.8
11	-4.	-4.	-4.
12	-25.	-23.	-24.

## Medical Magnet 58° C-Type

## Field-Shape Data


Per Cent Change From Center to


Edges X-Direction


Laminations  
= 0Position  
CentimetersRun I  
Per CentRun II  
Per CentRun Ave  
Per Cent

-1	-97.	-97.	-97.
-2	-91.	-91.	-91.
-3	-84.	-84.	-84.
-4	-77.	-77.	-77.
-5	-66	-68	-67
-6	-58	-60	-59
-7	-46	-49	-47
-8	-33	-35	-34
-9	-15	-18	-16
-10	-2	-4	-3
-11	+ .9	+1.0	+ .9
-12	.1	.1	.1
-13	.2	.1	.2
14	.0	0	0
15	.2	.1	.1
16	+ .5	+ .8	+ .7
17	-8.	-1.	-5.
18	21	23	22
19	34	41	38
20	54	56	55
21	65	63	64
22	73	72	73
23	80	79	80
24	88	87	88
25	94	94	94
26	100	95.	97.
27	100	100	100

Medical H-type magnet  $32^\circ$   
B verses I curve









58° Medical magnet c-type  
Percent change from center  
vs. position Run ave.  
 $B = 20.6 \text{ kG}$   $I = 1076 \text{ Amps}$

